Installing the Batteries

The SM-7000B/W optical mouse use two AAA alkaline batteries.

**Installing Batteries in the Mouse**

Step 1. Open the battery compartment

Step 2. Insert the batteries as shown inside the battery compartment.

Step 3. Replace the cover.

## Connecting the Receiver

USB Port

Nano receiver

1.Connect the USB plug **ONLY** to USB port of the computer.

Nano receiver

USB port

DPI Function

Your optical mouse 4D buttons mouse is provided with 1000 & 1600 dpi switch.

DPI Switch

Power-Save function:

* This mouse is equipped with Traveling-Power-Save function.
When you are traveling with this mouse, the LED of the mouse will be switched off automatically for the purpose of power-save, but the pre-condition is that the receiver is disconnected with your notebook or PC.

* when your mouse no any clik or scroll or moving, the mouse will come to sleep state for the economize after about 30 minutes, for the wake up, you can click any button for this

Restoring factory default settings

When you find this set doesn't work, you can make the mouse in working condition by restoring the mouse back to factory default settings.
1: check the battery volume is normal; if the battery is used out, please replace new batteries.
2: press the right button and middle button (under the scroll wheel) simultaneously ; then
3: insert the nano receiver onto the USB port of PC or notebook.

NEXUS

SM-7000 B/W

Instruction Manual

Silent Optical 2.4Ghz Mouse

CAUTION: To use this device properly, please read the user's guide before installation.

VER:00